



## Adjustment for Tracking The Satellite Arc




Adjustment Needed: Decrease Motor Latitude. Increase Declination.  
Move the Rotational Axis of the Dish Towards Horizontal.

Satellite Arc ————○—————  
Your Track - - - - -○- - - - -



Adjustment Needed: Increase Motor Latitude. Decrease Declination.  
Move the Rotational Axis of the Dish Away From Horizontal.



If your North/South Alignment is off, you will be Above the Arc on one side and below the Arc on the other side. Turn entire Polar Mount Assembly on the mast to correct.